

**DIESEL ENGINE**  
**C190GB, C190KE, C190, C240 MODELS**

# **WORKSHOP MANUAL**



**ISUZU MOTORS LIMITED**

The following manuals in English language version are available for use in inspection, adjustments and repairs of Isuzu light-duty truck and bus series.

MANUALS AVAILABLE		WORKSHOP MANUALS	SERVICE MANUALS
UNIT OR EQUIPMENT APPLICABLE			
ENGINE	: G161 : C190, C240 : 4BA1, 4BC1 : 4BD1	G161-WE-741 1924-WE-101 4BAC-WE-001 46BD-WE-011	
CLUTCH PROPELLER SHAFT TRANSMISSION REAR AXLE FRONT AXLE BRAKE STEERING SUSPENSION CHASSIS ELECTRICALS ENGINE ELECTRICALS INJECTION PUMP		LCLU-WE-001 LPRO-WE-001 LTRM-WE-001 LRAX-WE-001 LFAX-WE-001 LBRK-WE-001 LSTR-WE-001 LSUS-WE-001 LCEL-WE-001 HLEE-WE-001 —	INJ-SE-011

When design change is effected on some equipment for 1981 year model, the details of changes are outlined in the workshop manuals and those manuals are issued with the new publication number (○○○○-WE-011).

**ISUZU**  
**WORKSHOP MANUAL**  
**DIESEL ENGINE**  
**C190GB,C190KE,C190,C240**  
**MODELS**

**FOREWORD**

This manual includes special notes, important points, service data, precautions, etc. that are needed for the maintenance, adjustments, service, removal and installation of the components of the model titled.

All information, illustrations and specifications contained in this manual are based on the latest product information available at the time of publication.

The right is reserved to make changes at any time without notice.

Arrangement of the material is shown by the table of contents on the right-hand side of this page. Black spot on the first page of each section can be seen on the edge of the book below section title. A more detailed table of contents precedes each section.

This manual applies to the 1981 year and later models.

SECTION INDEX	
SECTION	NAME
1	GENERAL INFORMATION
2	ENGINE ASSEMBLY
3	LUBRICATING SYSTEM
4	COOLING SYSTEM
5	FUEL SYSTEM
6	INTAKE AND EXHAUST SYSTEM
7	AUXILIARIES
8	SPECIAL TOOL LIST
9	CONVERSION TABLE



## SECTION 1

## GENERAL INFORMATION

## INDEX

## CONTENTS

	PAGE
General repair instructions .....	1- 1
How to use this manual .....	1- 2
Application chart .....	1- 5
Main data and specification .....	1- 6
Torque specifications .....	1- 7
Engine repair kit .....	1-11
Servicing .....	1-13
Engine oil viscosity chart .....	1-30
Recommended lubricants .....	1-31

## GENERAL REPAIR INSTRUCTIONS

1. For assurance of safety, park the vehicle on level ground and brace the front or rear wheels when lifting the vehicle.
2. Raise the vehicle with a jack set against the axle or frame and perform service operation after supporting the vehicle on chassis stands.
3. Before performing service operation, disconnect grounding cable from the battery to reduce the chance of cable damage and burning due to short-circuiting.
4. Use a cover on body, seats and floor to protect them against damage and contamination.
5. Brake fluid and anti-freeze solution must be handled with reasonable care as they can cause paint damage.
6. The use of proper tools and special tools where specified, is important to efficient and reliable service operation.
7. Use genuine Isuzu parts.
8. Used cotter pins, gaskets, O-rings, oil seals, lock washers and self lock nuts should be discarded and new ones should be prepared for installation as normal function of the parts can not be maintained if these parts are reused.
9. To facilitate proper and smooth reassembly operation, keep disassembled parts neatly in groups. Keeping fixing bolts and nuts separate is very important as they vary in hardness and design depending on position of installation.

- 10. Clean the parts before inspection or reassembly. Also clean oil ports, etc. using compressed air to make certain they are free from restrictions.
- 11. Lubricate rotating and sliding faces of the parts with oil or grease before installation.
- 12. When necessary, use a sealer on gaskets to prevent leakage.
- 13. Carefully observe all specifications for bolt and nut torques.
- 14. When service operation is completed, make a final check to be sure service has been done properly.
- 15. For assurance of safety, always release air pressure solely from the air tanks before disconnecting pipes, hoses or other parts from any unit under air pressure.

HOW TO USE THIS MANUAL

- 1. Find the applicable section by referring to the index.
- 2. This manual includes "General information" section in which service data, maintenance items and specifications with torques are included.
- 3. Each section includes removal and installation, disassembly, inspection and repair and reassembly. When the same service operation applies to more than one units or equipments, notice is inserted stating, "Refer to manual for other units or equipments".
- 4. In removal and installation section, description of self-explanatory items such as removal of individual parts from unit to be removed, is omitted and important operation such as adjustments, torque specifications, etc. are dealt with mainly.

- 5. Each service operation section begins with disassembled view of unit or equipment which is useful to find components, service procedure, availability and content of repair kits, etc.

Example

**MAJOR COMPONENT**

This illustration is based on the 6 x 6 and 4 x 4 models.  
The steps of service operation designated as No. 3 - 12 are applicable to all models excluding 6 x 4.

Repair kit

ocose

"Note" indicating models applicable.
★ parts contained in repair kit.
Parts to be removed or installed as a unit.
All units or parts within frame are to be considered as "major component". Each unit or part within frame is to be considered as "minor component".
The number represents sequence of service operation.
Removal of the parts without number (excluding bolts, nuts, washers, gaskets, cotter pins, etc.) is unnecessary unless when replacement is needed. Where parts replacement requires specific note, instructions are given in "Inspection and repair".
★ indicates repair kit availability.
Name of parts listed in sequence of service operation.
▲ indicates important operation. Details of service operation are described in the paragraph "Important operations".


**Assembly steps**

- A1. Input shaft bearing
- 2. Input shaft snapping
- A3. Front output shaft bearing
- 4. Front output shaft snapping
- 5. Front output shaft
- 6. Shift fork and sleeve
- 7. Front drive shaft fork
- A8. Front output shaft sleeve
- A9. Front drive shaft rod and collar
- A10. Front drive shaft fork lock bolt
- 11. Front drive shaft rod detent ball, spring and seat
- A12. Front drive shaft fork lock wire
- A13. Input shaft
- 14. Shift fork, idle shaft and sleeve
- 15. Idle shaft assembly
- 16. High and low shift fork


**Disassembly steps**

- A17. Input shaft sleeve
- A18. High and low shift rod
- A19. High and low shift fork lock bolt
- 20. High and low shift rod detent ball, spring and seat
- A21. High and low shift fork lock wire
- A22. Rear cover assembly
- A23. Idle shaft shim
- 24. Idle shaft cover
- 25. Front output shaft distance piece
- 26. Front output shaft oil seal
- A27. Front output shaft flange and nut
- 28. Input shaft distance piece
- 29. Input shaft oil seal
- A30. Input shaft yoke and nut
- A31. Input shaft universal joint
- A32. Breather


6. The section following illustration(s) deals with important service steps marked with "▲". This section also includes "notes", "use of special tools", "service data", etc.



05018



05019



05077

**Important operations**

1. Input shaft bearing  
3. Front output shaft bearing  
Installer: 9-8522-0040-0

8. Front output shaft sleeve  
17. Input shaft sleeve  
The shift fork groove side faces downward

9. Front drive shift rod and collar  
18. High and low shift rod  
The parts include shift rods for high and low speed selection and for front drive.  
Direction of installation of the parts should be carefully noted.

10. Front drive shift fork lock bolt  
19. High and low shift fork lock bolt  
Torque (kg-m) 4 - 5.5

Item shown in the illustration and marked with "▲"

Special tools are identified with tool name and/or part number. The drawing illustrates how the tool is used.

Important note.

The symbol indicates the step of service to be followed. Refer to the following paragraph for meaning of each symbol.

Service data and specifications are listed in table.

7. In this manual, the following symbols are used to indicate the type of service operations to be performed.

	Remove		Adjustment
	Install		Clean
	Disassemble		Pay close attention — important
	Reassemble		Tighten to specified torque
	Align the marks		Use special tool(s) (Isuzu's tool(s))
	Correct direction		Use special tool(s) (parts manufacturer's tool(s))
	Inspect		Lubricate with oil
	Take measurement		Lubricate with grease

8. The service standard is indicated in terms of "Standard" and "Limit". The "standard" means the assembly standard and standard range within which the parts are considered serviceable. "Limit" indicates the limit value (Correction or replacement is necessary when measurement is beyond this limit.)
9. In this manual, the components and parts are printed in singular form.

## APPLICATION CHART

C190GB, C190KE ..... Engine with VE type injection pump and belt type timing drive train  
C190, C240 ..... Engine with in-line type injection pump and gear type timing drive train

Vehicle models	Engine models			
	Passenger car	C190GB	C190KE	C240
Light-duty trucks		○		
		*KBD		
		KBD	○	
		KAD	○	
		TLD		○

Model with \* mark ..... For special territories.

○ Applicable model

## MAIN DATA AND SPECIFICATIONS

Items	Engine model	C190GB C190KE	C190	C240
Engine type		Water-cooled, 4-cycle in-line, overhead valve type		
Combustion chamber type		Swirl chamber type		
Cylinder liner type		Dry type, Cromard liner		
Timing gear system		Belt drive		
No. of piston ring		Compression ring 2, oil ring 1		
No. of cylinder - bore x stroke	(mm)	4 - 86 x 84	4 - 86 x 84	4 - 86 x 102
Total piston displacement	(cc)	1,951	2,369	2,369
Compression ratio		20 : 1		
Engine dimensions : length x width x height	(mm)	Approx. GB730x570x625 KE696x666x715	Approx. 682 x 600 x 633	Approx. 685 x 606 x 685
Engine weight (dry)	(kg)	Approx. 220	Approx. 221	Approx. 223
Fuel injection order		15°	18°	14°
Fuel injection timing (B.T.D.C. static)		High-speed diesel fuel (SAE No. 2)		
Type of fuel used		Cartridge type		
Fuel filter type		Bosch distributor		
Injection pump type		VE type		
Governor type		Mechanical variable speed (half all speed)		
Injection nozzle type	(kg/cm <sup>2</sup> )	Throttle type		
Fuel injection pressure	(kg/cm <sup>2</sup> )	105	31 (at 200 rpm)	120
Compression pressure	(rpm)	GB 600 - 650 KE 675 - 725	675 - 725	
Idle speed		0.45		
Intake and exhaust valve clearance	(cold) (mm)	11° (B.T.D.C.) 49° (A.B.D.C.) 51° (B.B.D.C.) 9° (A.T.D.C.)		
Intake valve	open at	Pressurized circulation		
Close at		Gear type (4 x 4)		
Exhaust valve	open at	Rotor type (4 x 2)		
Close at		Paper element, full-flow type		
Lubrication method		Cartridge type		
Oil pump type		With oiling jets		
Oil filter type		Cartridge type		
Piston cooling	(liters)	GB 6.0, KE 6.5		
Lubricating oil capacity		Water-cooled		
Oil cooler type		Pressurized circulation		
Cooling method		9.0		
Cooling water capacity	(liters)	Impeller type		
Water pump type		Wax pellet type (with jiggle valve)		
Thermostat type		Cyclone type combined with paper element type		
Air cleaner type		NS70/NX120-7 - 12 x 1		
Battery type	— Voltage (V) x No. of unit	12 - 50/65/80		
Generator	Voltage — capacity (V—A)	12 - 1.8/2.2		
Starter	Voltage — output (V—KW)	12 - 1.8		

## TORQUE SPECIFICATIONS

## STANDARD BOLTS

The torque values given in the following table should be applied where a particular torque is not specified.


Bolt identification	Bolt diameter x pitch (mm)	4 T (Low carbon steel)	7 T (High carbon steel)	9 T (Alloy steel)
6 x 1.0		0.4 — 0.8	0.5 — 1.0	—
8 x 1.25		0.8 — 1.8	1.2 — 2.3	1.7 — 3.1
10 x 1.25		2.1 — 3.5	2.8 — 4.7	3.8 — 6.4
*10 x 1.5		2.0 — 3.4	2.8 — 4.6	3.7 — 6.1
12 x 1.25		5.0 — 7.5	6.2 — 9.3	7.7 — 11.6
*12 x 1.75		4.6 — 7.0	5.8 — 8.6	7.3 — 10.9
14 x 1.5		7.8 — 11.7	9.5 — 14.2	11.6 — 17.4
*14 x 2.0		7.3 — 10.9	9.0 — 13.4	10.9 — 16.3
16 x 1.5		10.6 — 16.0	13.8 — 20.8	16.3 — 24.5
*16 x 2.0		10.2 — 15.2	13.2 — 19.8	15.6 — 23.4
18 x 1.5		15.4 — 23.0	19.9 — 29.9	23.4 — 35.2
20 x 1.5		21.0 — 31.6	27.5 — 41.3	32.3 — 48.5
22 x 1.5		25.6 — 42.2	37.0 — 55.5	43.3 — 64.9
24 x 2.0		36.6 — 55.0	43.9 — 72.5	56.5 — 84.7

The asterisk \* indicates that the bolts are used for female-threaded parts that are made of soft materials such as casting, etc.



Crankshaft and camshaft

(kg-m)




OK902

MAJOR PARTS FIXING BOLTS

Cylinder head and cylinder body


(kg-m)



OK901




## (kg-m)



This diagram shows an exploded view of a mechanical assembly. The components are labeled with callout numbers in boxes: 1.5, 1.8, 2.5, and 7.5. The assembly includes a main housing, a central shaft with gears, and various smaller components like bolts, washers, and a cable. The callout 1.5 points to a cable and a small component. The callout 1.8 points to a large flange or cover. The callout 2.5 points to a cable. The callout 7.5 points to a long, thin component, possibly a shaft or a cable.

OK903

## C190GB, C190KE models




0K904

1. Gasket : cylinder head
2. Gasket : cylinder head cover
3. Gasket : intake and exhaust manifold
4. Gasket : joint bolt
5. Seal : crankshaft rear
6. Gasket : drain plug
7. Gasket : oil pan to case
8. Gasket : oil pan to bearing cap
9. Gasket : tappet cover
10. Gasket : water pump to cylinder block
11. Gasket : outlet pipe
12. Gasket : cylinder head to housing
13. Sealing ring
14. Gasket : oil filter to block
15. Gasket : throttle valve
16. Gasket : nozzle holder
17. Washer : corrugated, holder
18. Gasket : vacuum pipe
19. Oil seal: crankshaft, front
20. Gasket : body to housing
21. Gasket : pulley to pump
22. Gasket : head cover
23. Repair kit : top over haul

ENGINE REPAIR KIT

C190; C240 models




- 1. Gasket : cylinder head
- 2. Gasket : cylinder head cover
- 3. Gasket : intake and exhaust manifold
- 4. Gasket : joint bolt
- 5. Seal : crank shaft rear
- 6. Gasket : front plate
- 7. Gasket : drain plug
- 8. Gasket : oil pan to case
- 9. Gasket : oil pan to bearing cap
- 10. Gasket : tappet cover
- 11. Gasket : gear case
- 12. Seal : oil
- 13. Gasket : gear case
- 14. Gasket : gear case
- 15. Gasket : water pump to cylinder block
- 16. Gasket : outlet pipe
- 17. Gasket : cylinder head to housing
- 18. Ring : sealing
- 19. Gasket : oil filter to clock
- 20. Gasket : fuel pump
- 21. Gasket : vacuum pipe
- 22. Gasket : throttle valve
- 23. Washer : nozzle holder
- 24. Washer : corrugated, holder
- 25. Gasket : bracket to front plate
- 26. Gasket : vacuum pipe
- 27. Gasket : head cover bolt
- 28. Repair kit : top overhaul kit

SERVICING

CYLINDER HEAD




Tighten the cylinder head bolts in sequence as shown in the figure.




Torque	(kg-m)	8.0
--------	--------	-----

VALVE CLEARANCE




Adjust the valve clearances in the following manner using a feeler gauge.

Intake and Exhaust (in cold)	0.45	(mm)
---------------------------------	------	------




Turn the crankshaft until the TDC notched line on crankshaft pulley is aligned with the pointer to bring the piston in either No. 1 or No. 4 cylinder into top dead center on compression stroke. Hand-feel looseness of intake and exhaust valve push rods on the No. 1 cylinder. When both the push rods have a play, it indicates that the No. 1 piston is at top dead center on compression stroke. When the valves on No. 1 cylinder are pushed open, it indicates that the No. 4 piston is at top dead center on compression stroke.




1—14 GENERAL INFORMATION

AIR CLEANER



(C190GB, C190KE)


Check that notched line on the injection pump flange is in alignment with notched line on the front plate.



Adjustment

Bring the piston in No. 1 cylinder to top dead center on compression stroke by turning the crankshaft as necessary. With the front upper cover removed, check that timing belt is properly tensioned and that timing marks are aligned.



INJECTION TIMING



(C190, C240)

Timing	C190	18°
	C240	14°


Check that notched line on the injection pump is in alignment with notched line on the injection pump bracket.



Measuring device


Disconnect the injection pipe from the injection pump and remove the distributor head screw, then install measuring device.

The dial indicator should be installed with the probe depressed inward by approximately 2 mm.



Bring the piston in No. 1 cylinder to a point 30 — 40 degrees before top dead center by turning the crankshaft, then calibrate the dial indicator to zero.





Turn the crankshaft until the line 15° on damper pulley is brought into alignment with the pointer, then take reading of the dial indicator.



	(mm)
Standard reading	0.47 — 0.53
Timing	15°

Turn the crankshaft in normal direction of rotation.

If the injection timing deviates from the specified range, loosen pump fixing nuts and bracket bolts, then make an adjustment by varying injection pump setting angle.

- When larger than standard value;  
Turn the injection pump toward the engine so that the dial gauge indication falls within the standard value.
- When smaller than standard value;  
Turn the injection pump away from the engine so that the dial gauge indication falls within the standard value.

### TIMING PULLEY (C190GB)



#### Visual check




The belt must be replaced if cracks are found in the side and rear faces.

#### Timing pulley

If the timing pulleys are found to be fouled with oil or grease, clean with gasoline or light oil and wipe dry quickly.

#### Timing belt

Also replacement is necessary when abnormal wear is found in the side face.



Take measurements at 3 — 5 points around the circumference of the belt. The belt must be replaced even if a single measurement is beyond the limit.


Limit of rubber hardness (HS)	90
-------------------------------	----

Rubber hardness tester


### Timing belt replacement (C190GB, C190KE)

#### Removal


Remove the crankshaft pulley and pulley housing covers A and B, then remove the injection pump timing pulley flange.









Install the crankshaft pulley and bring the piston in No. 1 cylinder to top dead center on compression stroke. Check to make certain the mark "▲" on the injection pump timing pulley is in alignment with the mark "▲" on the camshaft pulley. Secure the injection pump pulley and camshaft pulley with the bolts.




Remove the crankshaft pulley, then remove the tension spring, tension bearing and tension center.

Replace the timing belt.



Check to make sure the mark on the timing pulley and on the crankshaft pulley are in alignment with the pointer. Set the belt on the crankshaft pulley, camshaft pulley and injection pulley in that sequence, then adjust to have the slackness of timing belt taken up by the tension pulley.



Install the tension center and tension bearing in the following manner: Install the tension center, so that its end is in proper contact with the pins on the front pulley. Install and hand-tighten the tension bearing nut. Install the tension spring and remove the pulley fixing bolts, then semi-tighten the tension bearing nut.

Nut semi-tightening torque	(kg-m)	3 — 5
----------------------------	--------	-------



Turn the crankshaft 2 turns in normal direction of rotation. Further turn the crankshaft 90 degrees beyond the top dead center. Loosen the tension bearing nut to take up slackness of the belt, then tighten the nut to specification.


Torque	(kg-m)	11 — 13
--------	--------	---------

Install the flange by aligning hole in the outer circumference of the flange with the mark "▲" on the injection pump. Turn the crankshaft 2 turns and check that timing marks "▲" on the pulleys are in alignment.

Injection timing

Refer to Section 1 general information on page 1-15 for Injection timing adjustment.

COMPRESSION PRESSURE




Remove the glow plugs from all cylinders, then check the compression pressure in each cylinder with a compression gauge by engaging starter.

Standard	Limit
31.0	22.0 — 23.0

Adaptor : 5-83571-002-0

(kg/cm<sup>2</sup> at 200 rpm)


FUEL SYSTEM



Injection nozzle


Check the spraying condition and injection starting pressure.

Injection pressure (kg/cm <sup>2</sup> )	C190GB, C190KE	105
	C190, C240	120




**Adjustment**

Adjust the injection starting pressure with the adjusting screw using a nozzle tester.



**Bleeding (C190, C240)**

Bleed the system by manually operating the priming pump with the fuel filter outlet joint bolt and injection pump bleeder screw loosened.





**(C190GB, C190KE)**

Fill the injection pump chamber with diesel fuel through the overflow valve hole.  
Move the hand pump located on the fuel filter up and down.



**Feed pump strainer (C190, C240)**

Remove the strainer using a screw driver. Wash the strainer in clean diesel fuel.



**Fuel filter replacement**

Remover and installer



Apply diesel fuel to O-ring. Turn in filter until sealing face is brought into contact with the O-ring. Further tighten 2/3 of a turn.

**Fuel sedimentor (if equipped)**





**Removal steps:**


1. Disconnect water separator sensor wiring at the connector.
2. Remove the filter using filter wrench.



Filter wrench




3. Remove the sensor from filter.



OK919

Installation steps

1. Install the sensor on a new filter.  
Apply diesel fuel to the O-ring before installation.



OK539

OK811



2. Fill the filter sufficiently with diesel fuel before installing it in the housing.  
Apply diesel fuel to O-ring. Turn in filter until sealing face is brought into contact with the O-ring. Further tighten 2/3 of a turn.

AIR CLEANER


Viscus type air cleaner. (PAD, KBD)

The viscus type air clearer element should not be cleaned for reuse and should be replaced with a new one.

Dry type air cleaner. (KAD, TLD)

Cleaning of element

When the element is fouled with dust  
Apply compressed air to the element from inside while turning it with hand. The pressure of compressed air should not exceed 7 kg/cm<sup>2</sup>.





OK154



Inspection of element

After allowing the element to dry completely, check for the damage using a light bulb within the element.



OK466




When the element is fouled sooty:

Prepare cleaning solution by diluting essential element cleaner (Donaldson D1400) with water and keep the element submerged in solution for about 20 minutes.  
Take out the element and rinse well with running water.  
Allow the element to dry in a well ventilated place or using an electric fan. Avoid use of compressed air or open flames for quick drying. It is recommended that a spare element be used as it normally takes 2 — 3 days for natural drying.

Oil bath type air cleaner (Option)

Wash clean the element in detergent oil, Wash the case to remove dust and other foreign matter.



OK213



OK214



Install the element and case after cleaning. Fill the oil pan to the specified level using engine oil.


Oil capacity	(liter)	0.7
--------------	---------	-----

LUBRICATING SYSTEM


Main oil filter

C240 only

Install the element assembly in sequence of spring (1) spring seat (2) and rubber gasket (3).




OK920





Radiator filler cap		(kg/cm <sup>2</sup> )
Pressure valve	Negative Pressure valve	
0.9 — 1.2	0.04 — 0.05	

ENGINE CONTROL



PAD model	
Inspection of accelerator pedal height from floor.	
Height (mm)	114

Tighten the nut B until play in the inner cable is completed removed. Adjust the clearance between the bracket and nut to 2 — 3 mm. Tighten the nut B until nut A makes contact with the bracket, then lock the nut B.




When adjustment at pump side is completed, check that accelerator pedal stroke is within the specified value.


Stroke (mm)	65
-------------	----

With oil cooler type


Remover and installer  
Filter wrench



Apply engine oil to O-ring. Turn in filer until sealing face is brought into contact with the O-ring. Further tighten 2/3 of a turn.



FAN BELT




Adjustment

Adjust belt tension by moving generator pulley.

Specified belt deflection (mm)	10
--------------------------------	----

RADIATOR



Install radiator filler cap tester on the radiator and check the cooling system for leakage by applying testing pressure. Testing pressure should not exceed the specified pressure.

		(kg/cm <sup>2</sup> )
Testing pressure	2.0	



KBD model

Inspection of accelerator pedal height from floor.

Height (mm)	94
-------------	----

Adjustment of pedal stroke

Stroke (A) (mm)	40
Clearance between pedal and pedal stopper bolt	
Clearance (B) (mm)	0 - 3

With the throttle valve closed completely, set the outer cable, so that play in the inner cable is removed. Back off the nut A one or two turns and lock the nut in that position with the nut B.


Play of inner cable (mm)	2 - 3
--------------------------	-------

Adjustment of idling


1. Start and let the engine idling until cooling water temperature reaches 70 - 80°C.
2. Returned the idling control knob to idling position.
3. Check that engine idling speed is within the range of from 600 - 650 rpm (PAD) or 675 - 725 rpm (KBD). If the idling speed deviates from the specified range, adjust with the throttle valve adjust bolt.

KAD, TLD models


The accelerator is controlled by means of the cable.




OK925






OK926



OK927




OK812



OK812

QUICK ON SYSTEM




Quick on system circuit diagram

A quick on start device is newly employed to minimize the time for preheating and to ensure easy starting.

Thermo switch

Operating temperature


Switch OFF	47 — 53°C or higher
Switch ON	43 — 50°C or lower



OK928

Glow plugs


Check for continuity across the plug terminals and body.



OK929

Fuel cut solenoid (VE pump only)


Check for continuity across the plug terminals and solenoid. Operation of solenoid can also be tested using a battery.



OK930


Fast idle control device (VE pump only)

Check the shaft for run-out at end of shaft against center of solenoid.




OK703

Measure the plunger stroke as it jumps out.



OK704

ELECTRICAL INTAKE SHUTTER (C190, C240)




OK931

Motor


Check to make certain the intake shutter operates properly when the starter switch is turned on.

Adjustment of cable

1. With the starter switch off loosen the nuts **A** and **B**. Pull the outer cable in direction of arrow until play in the inner cable is removed completely, then tighten the nut **A** temporarily.
2. Adjust the clearance between the bracket and nut **B** to 3 mm then turn in the nut **A**.
3. Check to make certain the engine stalls when the starter switch is turned off.



FUEL ENRICHMENT DEVICE (OPTION)




OK932

Adjustment of cable

1. Connect the joint at end of cable to the control lever.
2. Install the stopper clip in position between smoke set screw and control lever.
3. Pull the outer cable until play in the inner cable is completely removed.
4. Tighten the clamp bolt when play in the inner cable is removed.

5. Remove the stopper clip.
6. Clearance between control lever and joint.




OK933


Standard	(mm)	0.5 — 1.5
----------	------	-----------

Thermo switch

The thermo switch is preset to turn on at the coolant temperature of 10°C or below and to turn off when the coolant temperature increases beyond 10°C.



ENGINE OIL VISCOSITY CHART



RECOMMENDED LUBRICANTS

LUBRICATION	TYPE OF LUBRICANT	MAKE AND BRAND
Engine	Diesel engine oil CC or CD grade	<b>CC grade</b> *BESCO SUPER ENGINE OIL BP ENERGOL HD OIL BP VANELLUS M BP SUPER VISCO STATIC BP VISCO 2000 BP VANELLUS M MULTIGRADE CHEVRON DELO 200 MOTOR OIL CHEVRON DELO 100 MOTOR OIL CASTROL or DEUSOL CRB CALTEX FIVE STAR MOTOR OIL CALTEX RPM DELO 200 OIL CALTEX RPM DELO 100 OIL ESSOLUBE HDX ENI AGIP F.1 DIESEL GAMMA ENI AGIP F.1 SUPER MOTORIL ENI AGIP F.1 MOTOR OIL HD MOBIL DELVAC 1100 SERIES MOBIL HEAVY DUTY MOBIL SPECIAL MOBIL DELVAC SPECIAL MOBIL 1 SHELL ROTELLA SX OIL SHELL ROTELLA TX OIL SUNOCO SUNLUBE MOTOR OIL SUNOCO DYNALUBE MOTOR OIL SUNFLEET MIL-B TEXACO HAVOLINE MOTOR OIL TEXACO URSA OIL EXTRA DUTY TEXACO URSATEX TOTAL GTS TOTAL RUBIA H UNION HEAVY DUTY MOTOR OIL
		<b>CD grade</b> *BESCO S-3 ENGINE OIL BP VANELLUS C3 BP VANELLUS C3 MULTIGRADE CHEVRON DELO 400 MOTOR OIL CHEVRON DELO 300 MOTOR OIL CASTROL or DEUSOL CRD CASTROL or DEUSOL CRF CASTROL or DEUSOL RX SUPER CALTEX RPM DELO 400 OIL CALTEX RPM DELO 300 OIL ESSOLUBE D-3 ENI AGIP F.1 DIESEL SIGMA MOBIL DELVAC 1200 SERIES MOBIL DELVAC 1300 SERIES MOBIL DELVAC SUPER MOBIL DELVAC SHC SHELL RIMULA CT OIL SHELL RIMULA X OIL SHELL MYRINA OIL SUNFLEET SUPER C SUNFLEET DIESELUBE SUNFLEET DIESELUBE XD TEXACO URSA OIL SUPER TEXACO URSA OIL LA-3 TOTAL RUBIA S TOTAL RUBIA TM UNION GUARDOL MOTOR OIL

1-32 GENERAL INFORMATION

\*Mark ... Isuzu genuine lubricants

LUBRICATION	TYPE OF LUBRICANT	MAKE AND BRAND
Injection pump governor	Hydromaster and airmaster paste	BP SHOCK ABSORBER OIL CALTEX CAPELLA OIL 22WF CASTROL ICEMATIC 44 CHEVRON REFRIGERATION OIL 32 ENI AGIP F.1 TER 34 ENI AGIP F.1 SHOCK ABSORBER ESSO ZERICE 15 MOBIL GARGOYLE ARCTIC OIL LIGHT SHELL CLAVUS OIL 17 SUN SUMISO GS OIL SUNFILL M-3310 TEXACO CAPELLA OIL 22WF TOTAL LUNARIA 46
Engine cooling system	Permanent type anti-freeze solution	*ISUZU ANTI-FREEZE PT BP ANTIFROST CALTEX AF COOLANT CASTROL ANTI-FREEZE CHEVRON ATLAS PERMA-GUARD ANTI-FREEZE AND COOLANT ENI AGIP F.1 ANTI-FREEZE ESSO RAD MOBIL PERMAZONE SHELLZONE SHELL GLYCOSHELL PLUS SHELLSAFE TEXACO ANTI-FREEZE COOLANT TEXACO STARTEX ANTI-FREEZE COOLANT TOTAL ANTIGEL UNION YEAR AROUND ANTI-FREEZE AND COOLANT

SECTION 2  
ENGINE ASSEMBLY

INDEX

CONTENTS	PAGE
General description .....	2- 1
Removal and installation .....	2- 3
Disassembly .....	2-10
Inspection and repair .....	2-22
Reassembly .....	2-41

GENERAL DESCRIPTION

C190 C240 models

